

# Quick Setup Guide

step by step instructions  
for easy setup

Start Enjoying  
your New  
Como Audio  
Music System  
Now.

1

## Wait for Setup Wizard

After plugging in your unit, the Como Audio Logo will appear. Wait for the Setup Wizard to Start.

2

## Follow Setup Wizard

The next steps will help guide you through the setup wizard found on your unit's display. During the setup process, you may use the front panel controls on your music system **OR** your (included) remote control.



## Remote Control

power/on-off

info

scroll up

back/rewind

scroll down

source menu

mute/snooze

next/forward

select/play/pause/  
hold for menu

clock/alarm toggle

volume



COMO AUDIO



COMO AUDIO | [info@comoaudio.com](mailto:info@comoaudio.com)



# Setup Wizard

- 1 Start now?**  
Choose [YES]



Press to select  
**OR**  
press remote's  
select key.



- 2 12/24 hour format**  
Choose [12 or 24]



Rotate knob,  
press to select  
**OR**  
or press remote's  
back/next & select  
key.



- 3 Auto update**  
Choose [Update  
from Network]



Rotate knob,  
press to select  
**OR**  
press remote's  
select key.



- 4 Set Time Zone**  
Scroll to find your  
time zone.



Rotate knob,  
press to select  
**OR**  
use remote's  
up/down &  
select key.



**5 Adjust to DST**  
Daylight Savings  
Time  
Choose [+1 or -1]



Rotate knob,  
press to select  
**OR**  
press remote's  
back/next & select  
key.



**6 Network settings**  
Choose [YES]



Press to select  
**OR**  
press remote's  
select key.



**7 Network settings**  
Wait for Network  
wizard to find  
network.



If prompted,  
Select  
"Skip WPS"  
Option

**8 SSID**  
Scroll to find your  
personal wifi  
network.



Rotate knob,  
press to select  
**OR**  
press remote's  
up/down & select  
key.



- 9 KEY:** Enter your personal wifi password (case sensitive) When done, choose [OK] on right.

Your Remote Control works best when entering in your wifi password



Rotate & press knob to select character & symbols.

**OR** use remote's up/down, back/next & select key.



- 10 Network settings** Wait for Network to connect.



- 11 Setup Wizard Complete**



Press knob to select

**OR** use remote's select key.



- 12 Main Menu** Scroll through the many options to listen and enjoy.



Rotate knob, then press to select or press any preset button #'s 1-6

**OR** press remote's up/down & select key.



**PROBLEM?** Try performing a Factory reset and resetting your router.