



100 Bay State Drive, Suite 1, Braintree, MA 02184 USA

ATTENTION! PLEASE READ BEFORE USING!

Thank you for purchasing the Como Audio Turntable! Please read this important information to be certain your new Turntable sounds as it should.

1. If you're using your Como Audio Turntable with a Como Audio model or other model having an **Aux Input**, there is a switch on the bottom of the Turntable that must be set to the "**Line Out**" position first. Look at the Turntable from the back and lift it up from the back. The black module that houses the red and white RCA outputs includes a switch beneath the Turntable. Slide the switch toward you to the "**Line Out**" position *not* to "Phono". The illustration below shows the location of this switch. Setting the switch correctly will ensure the audio signal is at the level and equalization required for an *Aux input*. Only use the "Phono" position if connecting the Turntable to a device having a dedicated Phono input.



2. The Como Blu and Como Audio Turntable external power supplies are *not* the same. If you're using the Como Audio Turntable with the Como Blu Streaming Stereo System, please be sure to use the external power supply packed with Como Blu to power Como Blu, as using the Turntable's power supply to power Como Blu will result in a constant "low power" message.
3. Finally, if you're connecting the Como Audio Turntable to Como Blu's Aux input, please use the included adapter cable that converts the audio cable to a 3.5mm connector. Do *not* use the thick, black plastic adapter, as it will cover up the input to connect the external power supply.

If you have any questions about the setup, please contact the Como Audio Support Team at info@comoaudio.com or 1.844.644.8606, weekdays 9a -5p ET. We'll be happy to help.

Thank you for your attention. We hope you enjoy your new music system!

The Como Audio Team